



# PM5B Operational Manual



---

979 Second Street SE, Suite 309  
Charlottesville, VA 22902-6172 (USA)  
Tel: 434.297.3257; Fax: 434.297.3258  
[www.vadiodes.com](http://www.vadiodes.com)

---

<b>Section 1 – Contents, New Benefits and Safety</b> .....	<b>Pages 2-3</b>
Contents .....	Page 2
New Benefits / Safety: Read Prior to Activating Your PM5B .....	Page 3
<b>Section 2 – Control Descriptions, Specifications and Service</b> .....	<b>Pages 4-6</b>
Front Panel / Rear Panel / Sensor Head Overview.....	Page 4
Front Panel / Rear Panel Operational Details .....	Page 5
PM5B Specifications and Service .....	Page 6
<b>Section 3 – Starting and Operating the PM5B</b> .....	<b>Page 7</b>
<b>Section 4 – Settlement Times and Drift</b> .....	<b>Page 8</b>
<b>Section 5 – Tapers / Horn Antennas / Flange</b> .....	<b>Page 9</b>
<b>Section 6 – Power Meter Response Times</b> .....	<b>Page 10</b>
<b>Section 7 – PM5B Software Guide, USB and GUI</b> .....	<b>Pages 11-13</b>
Introduction and Software Startup.....	Page 11
GUI Control Buttons and Overview .....	Page 12
GUI Control Buttons' Detailed Functions .....	Page 13
<b>Appendix 1 – Programming / Commands / Communications</b> .....	<b>Pages 14-18</b>
Programming Communications and Commands to the PM5B .....	Page 14
Communications and Protocols from the PM5B .....	Page 15
Status Byte 1 / Status Byte 2 / Status Byte 3 Tables .....	Page 16
Response Return Format and Command Descriptions .....	Page 17
Set, Query and High Resolution Get Power Commands .....	Page 18
<b>Appendix 2 – VDI's Power Correction Factors</b> .....	<b>Page 19</b>
<b>Appendix 3 – Key Component Mechanical Drawings</b> .....	<b>Pages 20-21</b>
Sensor Head.....	Page 20
Waveguide Taper .....	Page 21
<b>Addendum – Product Updates and Company Contacts</b> .....	<b>Page 22</b>

# New Benefits and Safety

## Welcome to the PM5B

Congratulations. You have chosen Virginia Diodes' PM5B, an industry-leading solution for high frequency power measurement requirements. The PM5B is VDI's latest version of the Erickson calorimetric power meter and thanks to widespread industry acceptance, it has become the *defacto* standard for power measurement above 100 GHz. This highly accurate millimeter wave measurement tool is ideal for applications from 75 GHz to more than 3 THz. The PM5B supports power measurement ranges from 1  $\mu$ W up to 200 mW; it includes a WR10 sensor head and data collection software. A wide range of input waveguide tapers are available from VDI, making the PM5B a very flexible tool for high frequency applications. The PM5B delivers extremely wide bandwidth, excellent input match, low noise, high sensitivity and a USB interface powered by VDI's open source software for convenient operation and data collection.



## New Benefits and Features

The new PM5B delivers lower noise, allowing for faster and more sensitive measurements. The PM5B also has a new auto scaling feature that allows for faster range changes and offers the flexibility of remote control through its new USB connection and software. Customer-designed software can also interface with the PM5B thanks to open source coding.

## Safety



Read all instructions and information in this PM5B product manual before turning on or using your power meter. Start-Up & Operation procedures must be followed for proper function of the PM5B. If you have questions contact VDI at 434.297.3257 before using your power meter.

- 1) Use of any attachments not authorized by VDI may void the PM5B's limited warranty and could pose a hazard to the operator. Check with VDI before any measurement connection is attempted beyond the descriptions in this manual or if it may exceed commonly accepted standards of practice. (Tel) 434.297.3257 (Email) [Technical@vadiodes.com](mailto:Technical@vadiodes.com).
- 2) The PM5B is intended for use only with a power supply module or AC/DC converter supplied with the device by VDI. Use of other power supplies or converters could damage the device or injure the operator.
- 3) Do not connect or disconnect power cables or the sensor cable while the meter is switched on.
- 4) Avoid strong vibration or shock to the sensor head; do not drop the sensor head on the floor or any other hard surface.
- 5) EMC Registration is done on this equipment for business use only. It may cause interference when the product is used in the home. This warning statement applies to the product for business use.

## Virginia Diodes, Inc. (VDI) accepts no liability for damage or injury resulting from or caused by:

- Improper use or use for other purposes than those for which the PM5B was designed;
- Repairs carried out by persons other than VDI or its assigned agents;
- Tampering with or altering the power cord or sensor cable;
- Adjustment of machine components outside the parameters described in this manual.

### 사용자안내문


#### 사용자안내문

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 권과관심의 우려가 있습니다.

※ 사용자 안내문은 "업무용 방송통신기자재"에만 적용한다.


# Front Panel / Rear Panel / Sensor Head Overview

## Front Panel




## Rear Panel

3



## Sensor Head, Waveguide and Taper



# Front and Rear Panel Operational Details

## Front Panel



**Range Switch:** Used to select fixed ranges of 200  $\mu\text{W}$ , 2 mW, 20 mW and 200 mW. Also enables Auto Scale Mode and USB control when “Remote” is selected. The meter requires a relatively long wait for the thermal transients to settle; it settles more quickly when shifting ranges upward than it does when shifting ranges downward. Avoid going higher in ranges if you plan to immediately return to a lower range setting. See Section 4. Higher ranges have faster responses; using the highest range with sufficient resolution is recommended. The maximum measurable power for all ranges is limited to the full scale power (with 0 dB cal factor). Exceeding full scale power leads to a large imbalance in the normally closed loop and lengthy sensor recovery time.

**Zero Button:** Is used to zero the display with no effect on calibration. The meter will drift rapidly after turn-on and range switching; under some conditions it will drift slowly but steadily for several minutes. See Section 4. When in Auto Scale Mode the Zero Button has additional functionality: A) Press Zero Button once in any scale  $>200 \mu\text{W}$  to turn on Range Hold; B) Press Zero Button twice (within 0.75 seconds) to turn off Range Hold; C) Press Zero Button three times quickly while in Auto Scale Mode in the 200  $\mu\text{W}$  scale and the PM5B will simultaneously zero all four ranges. If the meter is over-ranged, pressing the Zero Button three times quickly will readjust internal settings for the active range to achieve full scale readings above the zero point, if possible. It is strongly recommended that the meter be allowed to settle before pressing the Zero Button three times quickly. **Note:** If possible, zero the power meter when the sensor head is connected to the device under test and the device under test is turned off.

**Sensor Head Connector Port:** This is a standard Amphenol connector, Series C091A, Part T3504001. Do not connect or disconnect the sensor cable if power is turned “On.” Contact VDI if you have questions about using longer cables.

**Cal Factor Switch:** Used for scaling the meter display to correct for input loss or gain; scaling applies only to the Front Panel Display and the GUI when measurement software is in operation via the USB. Scaling the meter does not affect the raw USB output or analog output. The switch reads in log (dB) units with 0 corresponding to no correction. Positive values correspond to correcting for input loss and negative values correspond to correcting for input gain. The maximum correction is  $\pm 29.9$  dB. The correction for the internal waveguide loss is only about 0.2 dB at 100 GHz. See Section 5 for details about using tapers and horn antennas. See Appendix 2 for a detailed description of WR10 SWG and taper frequency dependent insertion loss.

## Rear Panel



**Power Switch:** The power control is on the back panel since it is not expected that this instrument will be turned “ON” or “OFF” frequently. Do not turn the power switch from “ON” to “OFF” in quick succession because improper start-up may occur in some of the logic, which can lead to operational problems.

**Best Practice:** Wait at least 5 sec with the switch “OFF” before turning it “ON” again.

**Internal Calibration Switch:** The sensor element may be heated with known amounts of DC power for examination of the thermal response. The Internal Calibration Switch may be used to apply powers of 0.100, 1.00, 10.0 and 100 mW to the sensor. Under remote control via the USB, calibration voltages may be turned “ON” and “OFF,” but only if the switch is set to any position except “OFF.”

**Calibration Input via Banana Jacks:** The rear panel banana jacks are buffered and therefore not connected directly to the sensor calibration heater resistor, which has a value of 1000 $\Omega$ . If you wish to check the calibration at other heat values you may apply any voltage up to 12.7 V to the banana jacks with the Internal Calibration Switch set to the “Off” position.

**Analog Output:** A BNC connector is provided to interface the meter to other equipment. It provides a linear output of -10 to +10 VDC, with +10 VDC corresponding to full scale power on each range and 0 VDC corresponding to 0 mW. The analog output data rate is 1 Hz on the 200  $\mu\text{W}$  scale, 5 Hz on the 2 mW scale, 20 Hz on the 20 mW scale and 35 Hz on the 200 mW scales. Output impedance is  $\sim 0$  ohms.

**USB Port:** This meter utilizes a USB (Type B port) interface to enable full control of the PM5B via the VDI software or customer-designed programs. The supplied flash memory stick contains an MS Windows graphical interface with the original Labview 7 code to set the scale, zero the meter, read the data, and write data to a log file at chosen intervals. See Section 7 for a Graphical User Interface (GUI) overview. A detailed programming guide is located in Appendix One.

## Typical Specifications

- Input is WR10 waveguide (1.25 x 2.5 mm) with UG387 Flange. Useful frequency response is 75 GHz through the submillimeter range, extending even to the visible.
- Rear banana jack plugs provide a buffered connection to a 1 k $\Omega$  heater resistor (on the RF load), which is used for DC calibration. This connection enables internal calibration checks on all of the meter's ranges. Maximum response is up to 12.7 V. Absolute maximum is 25 V.
- RF accuracy is typically  $\pm 5\%$ .
- Maximum VSWR <1.15:1 in 80-110 GHz band. VSWR is expected to be similar or better at frequencies up to 2000 GHz.
- Analog output BNC connector on back panel: -10 to +10 VDC, with +10 VDC corresponding to full scale power on each range and 0 VDC corresponding to 0 mW.
- A USB (Type B) port is provided for full instrument control.
- Temperature drift is compensated to <2  $\mu\text{W}/^\circ\text{C}$ .
- Auto Scale Mode allows for relatively rapid range changes (~30 seconds) compared to the normal ranges. The range will change automatically based on input power.
- Operational temperature range: 10-30 $^\circ\text{C}$ .
- Required power: 100-240 V / 50-60 Hz.

## Typical Performance

Scale (FS)	Time for 90% Response*	Analog/Digital Update Rate	RMS Noise (USB out)	Display Update Rate	RMS Noise Display
200 mW	0.15 s	35 Hz	0.5 $\mu\text{W}$	4 Hz	$\sim 0.2 \mu\text{W}$
20 mW	0.2 s	20 Hz	0.2 $\mu\text{W}$	2.5 Hz	$\sim 0.08 \mu\text{W}$
2 mW	0.6 s	5 Hz	0.04 $\mu\text{W}$	2.5 Hz	0.03 $\mu\text{W}$
200 $\mu\text{W}$	12.0 s	1 Hz	0.003 $\mu\text{W}$	1 Hz	0.003 $\mu\text{W}$

\***Figure 1:** Response time is given as the time from application of an input to a response at the analog output of 90% of the final reading. Specifications are typical for changes in power greater than 0.075% of full range.

## Servicing the PM5B

Call 434.297.3257 for service details or email VDI at: [Technical@vadiodes.com](mailto:Technical@vadiodes.com).



Careful review of the instructions in the “ReadMe” file on the flash memory drive included with your new PM5B is recommended. It is critical that all instructions are followed for downloading files onto your computer before connecting the computer and meter via a USB cable. Call VDI at 434.297.3257 with any questions prior to: connecting the power supply or a computer to the PM5B, or starting the meter.



1. Follow installation instructions on the “ReadMe” file that was provided on the USB memory drive you received with your new PM5B meter.
2. If remote operation is desired, be sure to install the VDI-provided software BEFORE proceeding.
3. With the PM5B Power Switch (rear panel) in the “OFF” position, connect one end of the sensor cable to the front panel port of the PM5B readout; connect the other end to the PM5B sensor head.
4. Connect the AC power cable to the rear panel of the PM5B in its three-prong AC input socket.
5. Connect the USB cable to the USB port (Type B) on the back panel of the PM5B; connect the opposite end of cable to a compatible USB port on the computer to be used in conjunction with the PM5B. (Optional)
6. Turn on the PM5B by flipping the power switch to the “ON” position: ‘—’ = “ON”; “O” = “OFF.”
7. Do not rapidly toggle between “ON” and “OFF” settings as this will temporarily cause inaccurate meter readings. Maintain an “ON” or “OFF” setting at least 5 seconds before switching to the opposite setting.
8. Turn the Range Switch knob on the front panel of the PM5B to a selection appropriate for the power measurement. If you plan to make a number of measurements across increasingly higher power levels, begin with the lowest level, then proceed to higher settings.
9. Allow enough time for PM5B to settle; see PM5B Product Manual for **Settlement Times and Drift**, located in **Section 4**.
10. See PM5B Product Manual concerning **Use of Tapers in High Frequency Measurements**, located in **Section 5**.
11. Review conditions affecting **Power Meter Response Times**, located in **Section 6**.
12. See additional information detailing **PM5B software**, the **USB** and **GUI**, located in **Section 7**.

## Modes of Operation: Range Switch Selections

**Fixed Range Mode:** Fixed Range Mode can be entered by setting the Range Switch to 200  $\mu$ W, 2 mW, 20 mW, or 200 mW; the setting selected reflects maximum measurable power for a given range. Drift (see Section 4) and Response Time (see Section 6) should be considered when choosing a range. Fixed Range Mode can also be controlled via the USB when the Range Switch is set to “Remote.” When in “Remote” the virtual Range Switch displayed in the GUI operates as described above. Custom program ranges can also be set by sending the appropriate command via the USB (see Section 7).



### Range Switch

Select full-scale ranges from 200  $\mu$ W to 200 mW. ‘Remote’ enables USB control and auto range-scaling; virtual controls are viewable on the GUI.

**Auto Scaling Mode:** Auto Scaling Mode is entered automatically when the Range Switch is set to “Remote” and can be fully controlled via the USB (see Section 7). It is generally used to rapidly switch between fixed ranges with much shorter settling times. This mode of operation has four ranges like Fixed Range Mode; however, in Auto Scaling Mode they become 200  $\mu$ W auto, 2 mW auto, 20 mW auto, or 200 mW auto. When Range Hold is “OFF” the instrument automatically adjusts range based upon input power.

**Range Hold:** This feature fixes the range of the instrument and can be turned “ON” or “OFF” when in Auto Scaling Mode in any of the three upper ranges (2 mW auto, 20 mW auto or 200 mW auto). Turn “ON” by pressing the Zero Button while in an upper range (2 mW auto, 20 mW auto or 200 mW auto); turn “OFF” by pressing the Zero Button twice within 0.75 seconds. The Range Hold feature can also be cycled “ON” or “OFF” via the USB by using VDI software (see Section 7), or by sending the appropriate command via the USB in a custom program.

The sensor is sensitive to small internal temperature gradients; measurements as indicated in the Display will drift slowly in response to many influences, but this drift is small. Typical drift level does not usually exceed  $\sim 50 \mu\text{W}$  under normal conditions and is frequently much less.

Each power range selectable on the Front Panel of the PM5B is tuned to operate as fast as possible with acceptable noise and drift. Higher scales have faster responses, so it is recommended to use the highest scale with sufficient resolution. Switching ranges upward is practical with short settling times. Switching from higher to lower power ranges requires a longer wait for the thermal transient to settle. Switching more than one position downward requires a longer time to settle; it is recommended to avoid going up in scale if you plan to immediately return to a lower scale. After switching ranges from high to low (particularly from 200 mW to 200  $\mu\text{W}$ ), the sensor will drift for one to two hours. This drift will be slow enough to permit use within 10-15 minutes. A complete settling to the original zero may take a few hours.



The sensor also drifts in response to ambient temperature. This drift is partially compensated during manufacture, but the residual drift is  $\sim 2 \mu\text{W}/^\circ\text{C}$ . Higher drift may be seen due to ambient temperature variation if the temperature changes too fast for the sensor to stay in full equilibrium; full equilibrium takes over one hour to achieve under such conditions. Significant drift and zero offset can be induced by physically rotating the sensor head.

A noticeable source of apparent drift is due to the wideband response of the sensor. The sensor response band extends from 60 GHz to at least the visible spectrum, and so it responds to thermal emission from any object. Viewing an object only a few degrees warmer than the surroundings produces a response.

When measuring very low power levels (below 10  $\mu\text{W}$ ), it is essential that the sensor be connected to the source for at least a few minutes with the source “OFF” to establish the zero level. With the meter stabilized and zeroed, turn on the source without disturbing the connection to the sensor. If the source produces significant heating when “ON,” this can still produce a response that mimics output power in two different ways: first, through simple thermal conduction down the connecting waveguide; second, through wideband thermal emission. It is critical when measuring low power levels to be sure you are not measuring a simple heating effect.

When measuring power levels  $< 10 \mu\text{W}$ , the following procedure is recommended:

1. Allow the meter to stabilize;
2. Make a base measurement with no RF power applied to the sensor;
3. Apply RF power to the sensor;
4. Wait an appropriate amount of time determined by the range of the meter and accuracy required (see Section 6);
5. Take the power measurement;
6. Calculate the difference between this power measurement and the baseline measurement, this is the detected power;
7. Repeat this procedure and average the detected power as necessary.

### Tapers and their Role in High Frequency Measurements

When measuring signals of frequencies higher than the WR10 waveguide band, but within standard higher bands, best accuracy is obtained by inserting a linear waveguide taper between the source and the meter input. Such tapers between WR10 and all higher bands are available as standard microwave components from VDI, and typically have a length of about 1 inch. These tapers need not be very long or optimally shaped for low mode conversion, since the sensor load responds well to higher waveguide modes.




### Using Horn Antennas

For free space beams at any frequency, a gradually flared horn (beginning with WR10) should couple radiation into the sensor waveguide with good efficiency. Within the WR10 band the horn must precisely match the beam properties since the waveguide carries only one mode in band. At much higher frequencies, the horn should be sized so that the aperture is somewhat larger than the expected beam size, and a precise beam match is not needed, since the waveguide can carry several modes. DO NOT use a horn tapering down to single mode size, and then a taper up to WR10, since this adds greatly to the waveguide loss, and makes mode matching much more critical.

### Flange Details




The UG387 waveguide Flange is nickel plated copper and its tapped holes can be stripped very easily compared to waveguide parts constructed of different metals. Repair of the waveguide Flange is difficult once threads are damaged. Do not over-tighten these screws since this leads to progressive thread damage. There is no advantage to tightening these screws beyond initial snug contact between flanges. VDI has supplied a 1" section of WR10 waveguide to help prevent damage to the sensor Flange. VDI recommends the use of this section for all measurements. Please see information about tapers at the top of this page and Appendix Two: "VDI's Power Correction Factors."



#### Caution


Tapped holes in the nickel plated copper waveguide Flange can be easily stripped.



**Figure 2:**


Interface Flange for 1-inch and 2-inch waveguides. WR10 waveguide is shown above. All dimensions are in inches.

The following plots show the actual response of a sensor measured at 90 GHz. The response is not a simple exponential. It instead shows evidence of multiple time constants. It takes more than twice as long to reach 99% of the final measured response than it does to reach 90%. For the most consistent and accurate measurements, wait the 99% response time given in the figures below.




**Figure 3:**

Response on the 200  $\mu$ W scale. 90% response is at 12 sec. while 99% is at 31 sec. After 60 sec. the reading changes insignificantly.



**Figure 4:**

Response on the 2 mW scale. 90% response is at 0.6 sec. while 99% is at 5 sec. After 8 sec. the reading changes insignificantly.




**Figure 5:**

Response on the 20 mW and 200 mW scales. After 3 sec. the reading changes insignificantly. Response settled to 99% is at 1.0 sec. for 20 mW and 0.4 sec. for 200 mW. The overshoot amount varies with sensor, and is not observable on the front panel Display because it averages 8 individual readings of the USB port.



The PM5B has a USB interface that can be used to control all meter functions. Be sure to review the “ReadMe” file contained on the flash memory drive provided by VDI with your PM5B. The Graphical User Interface (GUI) is Windows based.

- 1) The flash drive should autorun program installation;
- 2) If the program does not auto-load, run “setup.exe”;
- 3) Connect the power meter to the computer to be used for all measurements and data collection using a USB (Type B) cable at the meter and requisite connection jack for your computer;
- 4) Next, turn on the power meter, so that the drivers may be automatically loaded;
- 5) Run “PM5B.exe” installed during setup in the installation directory. Doing so will open the window shown in Figure 6;
- 6) Enter the serial number found on the sensor head in the “SN#” field. Default is 235V;
- 7) Run the program by clicking on the arrow in the top left corner;
- 8) Clicking the Run Continuously button from “ON” to “OFF” will stop the program.



**Additional GUI  
Control Button  
Information:  
Pages 12-13**



**Figure 6:**

Screen shot of PM5B.exe user interface start-up screen. The graph is a generic Labview 7 graph control with the exception of the “Clear” button, which erases previous data points and the “Change to  $\mu$ W” button which switches the Y-axis units between milliwatts and microwatts. The full Labview 7.0 version of this program can be found on the flash memory drive.

# GUI Control Button Overview

Each button in the top row of the Graphical User Interface (GUI) implements a function when clicked

The screenshot shows the 'PM5 communication.vi' GUI. At the top, a row of buttons includes 'Getting Power', 'Zero', 'Set Range', 'Set Cal Heater', 'Log File Settings', 'Start Logging', 'Start StripChart', and 'Get Rev.'. Below these are various control panels for 'Range', 'Range Hold', 'Calibration Heater', and 'Run Continuously'. A 'Status' panel shows 'Range: Off', 'Remote/Local: Local', 'Cal Heater Switch State: Off', and 'Cal Heater Status: Off'. A 'Measurement Interval' panel has a 'Time (S)' field set to 0. A 'High Resolution' panel has an 'OFF' button. At the bottom, a 'Strip Chart' displays 'Output Power (mW)' vs 'Time (S)'. A 'Version' field is also present.

**Get Power**  
returns the measured power from PM5B

**Zero**  
is equivalent to the front panel 'Zero Button'

**Set Range**  
changes range to value selected by 'Range' knob below 'SN#'

**Set Cal Heater**  
sets value selected by 'Calibration Heater' knob

**Log File Settings**  
opens window to name a file for logging power measurements

**Start Logging**  
starts or stops logging data to a selected file

**Start Strip Chart**  
starts or stops plotting to the graph below

**Get Rev.**  
populates the 'Version' field with the PM5B firmware revision number

**Run Continuously**  
starts / stops continuous data collection

**Measurement Interval**  
sets time (Sec) between points in strip chart plot

**High Resolution**  
switches command set; returns more measured data bits

**Range Hold**  
applies / holds setting selected by 'Range' knob

**Range**  
selects power range to be measured

**Calibration Heater**  
reflects values chosen

**Status**  
shows settings of all major meter functions

**Strip Chart**  
displays measured data while it is being collected and logged

# GUI Control Button Details

## Each button in the top row of the Graphical User Interface (GUI) implements a function when clicked

- “Get Power” returns the measured power from the PM5B.
- “Zero” is equivalent to the front panel “Zero Button” on the instrument.
- “Set Range” changes the range to the value selected by the “Range” knob below the serial number field.
- “Range Hold” applies and also holds the range setting selected by the “Range” knob.
- “Set Cal Heater” sets the calibration heater according to the value selected by the “Calibration Heater” knob to the right of the “Range” knob.
- “Log File Settings” opens a window that allows browsing file names/locations in which to place logged readings. It also allows creating an original filename and location for logging power measurements to a text file.
- “Start Logging” starts and stops logging data to a selected file.
- “Start Strip Chart” starts and stops plotting to the graph at the bottom of the program’s window.
- “Get Rev.” returns the revision number of the PM5B firmware and places this number in the “Version” field.

## Other GUI Controls and Indicators

- “Measurement Interval” sets the time in seconds between points for plotting to the Strip Chart and logging to a file. The program will attempt to achieve this time, but will not be able to go faster than the sampling rate of the PM5B as described in the specifications.
- “High Resolution” switches the program to a different command set that returns more bits when measuring power. The default command set returns 16 bits for the power measurement over the USB (same rate as PM4). However, the PM5B has up to 10 times less noise. Sixteen bits does not provide enough resolution to realize the full benefits of the noise improvements of the PM5B; therefore, the PM5B also responds to a new command for measuring power that returns more bits. The PM5B does not return the status byte while returning a power measurement with higher resolution. When “High Resolution” is “ON” the calibration factor used for the GUI outputs will not be updated until “High Resolution” is turned “OFF.”
- “Status” shows the settings of all meter functions. The settings of the switches determine which functions are enabled.
- “Remote/Local” shows the front panel range switch setting. “Local” refers to any range other than “Remote.” In “Local” the GUI cannot set the range, but will perform the other functions.

Any selection of the back panel calibration heater switch other than “OFF” allows full control of the calibration heater. For example: Even on the 200  $\mu$ W setting, the meter can be calibrated on any range.

- “Cal Heater Switch State” shows the position of the rear panel switch.
- “Cal Heater Status” shows the actual calibration setting.

The last row of the GUI shows the setting of the “Cal Factor” front panel switch.

The PM5B power meter has a USB Type B connector jack at the rear that can be used to interface with the instrument. The USB interface uses an FTDI chip (Future Technology Devices International). Commands can be sent and received by a computer as a series of bytes by using FTDI device drivers. The bytes can be sent using the function “FT\_Write” in the device driver FTD2XX.dll, and the return bytes can be read with “FT\_Read”. The Labview library “PM5B.lib” includes the programming diagrams that calls functions in FTD2XX.dll to send and receive data via the USB. Alternately, the USB interface will also be installed as a Virtual COM port to allow communications with software designed to communicate using COM ports. Also included on the memory stick provided by VDI are other Labview VIs that use other functions in FTD2XX.dll not used by the “PM5B Communication.vi” program. See the “FTD2XX programming guide” on the memory stick for more information about controlling communication via the USB.

Communications to the PM5B that are similar to the PM4 must contain eight byte characters. All messages are prefaced with the synchronizing character “!” (0x21) or “?” (0x3f) and terminated with a carriage return (x0d). There is no checksum or other method of validation within the protocol.

The first, second, third and last bytes are ASCII characters. The first, second and third bytes are the command characters as shown in Table 1 below. “Set” commands start with the character “!”. In this instance values are written to the PM5B. “Query” commands start with the character “?”. In this instance the PM5B writes values to the computer. Bytes 4 through 7 are binary. Of the binary bytes, Byte 4 is the LSB and Byte 7 is the MSB. Bytes 4 through 7 are ignored by most of the commands, except Byte 4 represents rangehold (1-hold, 0-autorange) for the auto scales.

### For Communication to the PM5B

**Table 1:** Command Set for PM5B USB Communications

Byte 1	Byte 2	Byte 3	Command
			<b>Set Commands</b>
!	'null'	'null'	No action
!	S	Z	Set Zero (same as pushing zero button)
!	S	C	Calibrate
!	R	1	Set FP Range 200 $\mu$ W
!	R	2	Set FP Range 2 mW
!	R	3	Set FP Range 20 mW
!	R	4	Set FP Range 200 mW
!	R	5	Set FP Range 200 $\mu$ W auto
!	R	6	Set FP Range 2 mW auto
!	R	7	Set FP Range 20 mW auto
!	R	8	Set FP Range 200 mW auto
!	C	0	Calibration Heater OFF
!	C	1	Calibration Heater 100 $\mu$ W
!	C	2	Calibration Heater 1 mW
!	C	3	Calibration Heater 10 mW
!	C	4	Calibration Heater 100 mW
			<b>Query Commands</b>
?	'null'	'null'	No action
?	V	C	Query firmware code
?	D	1	Transmit Request one sample
?	D	S	Transmit Stream samples

# Communication Protocol / Communication from the PM5B

## PM5B Communication Protocol

On receipt of a message, the PM5B will acknowledge with an ACK (0x06) if the message was received and parsed correctly or a NAK (0x15) if it was not. "Parsed correctly" is defined as receiving eight bytes, starting with the synchronizing character "!" (0x21) or "?" (0x3f) and terminating with a carriage return (x0d). The action requested by the command is begun upon the correct parsing of the command.

Because this action may take many milliseconds to complete, the ACK only indicates the correct parsing, not the completion of the action. It is assumed that the action will complete successfully. The protocol does not provide detailed fault information.

The PM5B assumes the host is always capable of receiving messages and will only transmit a single message in response to a command. The host must be capable of accepting unsolicited messages back-to-back in rapid succession; this situation will occur if streaming power output data is requested. The host must not respond with an ACK nor a NAK upon receipt of power output data.

## For Communication from the PM5B

The response from the PM5B has a six byte message format. Byte 1 is an ASCII character. Byte 2 can be an ASCII character or straight binary depending on Byte 1. Bytes 4 through 6 are straight binary. The response returned from the query 'D1' or 'DS' has the following format:

Byte 1 is 'D'.
Byte 2 is the LSB of the data.
Byte 3 is the MSB of the data.
Byte 4 is Status Byte 1.
Byte 5 is Status Byte 2.
Byte 6 is Status Byte 3.

No response from the host is expected after receipt of this message. In the returned response, Bytes 2 and 3 together constitute the data in 16 bit integer format (short integer). These two bytes should be unpacked as a 16-bit integer. In addition, these are 16-bit 2's complement numbers, which will need to be converted from 16 bit 2's complement to decimal.

At this point, after converting to decimal, we have a number that is the raw count value (let us call this number countvalue). The actual reading is then computed from the countvalue, and based on what the range value is, and if there is a cal factor set in the front panel. The formula to get the reading from the countvalue and range value (defined here as variable rangeval):

$$\text{reading} = \text{countvalue} * 2.^{\text{rangemax}(\text{rangeval})} / 59576.$$

where rangemax = 200.E-6 for rangeval=1, or 2.E-3 for rangeval=2, or 20.E-3 for rangeval=3, or 200.E-3 for rangeval=4. The range value setting is also available in the status bytes (see below). If there is a cal factor on the front panel, the reading from the formula above should be further modified as:

$$\text{reading} = \text{reading} * 10^{(\text{calfactor}/10.)}$$

where calfactor is the decimal calfactor that you can read from the front of the panel.

This cal factor is also present in Status Byte 3 – See all three Status Byte definition tables on the next page.

# Status Bytes 1, 2 and 3 Definition Tables

## Status Byte 1 Definition:

bit 7	<b>Auto Range</b>	
	1	In auto range
	0	Not in auto range
bit 6:4	<b>Cal Heater</b>	
	000	OFF
	001	100 $\mu$ W
	010	1 mW
	011	10 mW
	100	100 mW
bit 3:1	<b>Rear Cal Switch</b>	
	000	OFF
	001	100 $\mu$ W
	010	1 mW
	011	10 mW
	100	100 mW
bit 0	<b>Local/Remote</b>	
	1	Remote
	0	Local

## Status Byte 2 Definition:

bit 7:4	<b>Cal Factor</b>	ones digit, binary encoded
bit 3:0	<b>Cal Factor</b>	decimal point digit, binary encoded

## Status Byte 3 Definition:

bit 7:5 Range Status Bits	<b>Range Selected</b>	Auto determined by Byte1 bit7
	000	OFF, no range selected
	001	200 $\mu$ W
	010	2 mW
	011	20 mW
	100	200 mW
	111	Error, multiple ranges selected
bit 4	<b>Cal Factor</b>	Sign digit, 1 is "-", 0 is "+"
bit 3:0	<b>Cal Factor</b>	tens digit, binary encoded

# Response Return Format and Command Descriptions

The response returned from the query “VC” has the following format:

Byte 1 is “V”
Byte 2 is “C”
Byte 3 is the decimal portion of the firmware code revision
Byte 4 is the integer portion of the firmware code revision
Byte 5 is the decimal portion of the secondary firmware code revision
Byte 6 is the integer portion of the secondary firmware code revision

**Example:** In firmware code Rev. 1.2 and secondary firmware code Rev. 3.5, the following string would be received: VC2153. No response from the host is expected after receipt of this message.

## Detailed Command Description

### Set Commands

**SZ** – will set the zero for the current range. This is the same as pressing the front panel Zero Button. Bytes 4-7 must be sent but the receiver ignores. The value will be stored in the serial EEPROM.

**SC** – will set the calibration for the current range. It is presumed that when this command is sent the calibration heater is set at exactly half scale for the range, and has had enough time to settle. Bytes 4-7 must be sent but the receiver ignores. The value will be stored in the serial EEPROM.

**R1** – if the front panel rotary switch is set to “Remote,” this will change the range to 200  $\mu$ W. Bytes 4-7 must be sent but the receiver ignores.

**R2** – if the front panel rotary switch is set to “Remote,” this will change the range to 2 mW. Bytes 4-7 must be sent but the receiver ignores.

**R3** – if the front panel rotary switch is set to “Remote,” this will change the range to 20 mW. Bytes 4-7 must be sent but the receiver ignores.

**R4** – if the front panel rotary switch is set to “Remote,” this will change the range to 200mW. Bytes 4-7 must be sent but the receiver ignores.

**R5** – if the front panel rotary switch is set to “Remote,” this will change the range to 200  $\mu$ W auto. Byte 4 turns on Range Hold with a value of 1 and turns off range hold with a value of 0. Bytes 5-7 must be sent but the receiver ignores.

**R6** – if the front panel rotary switch is set to “Remote,” this will change the range to 2 mW auto. Byte 4 turns on Range Hold with a value of 1 and turns off range hold with a value of 0. Bytes 5-7 must be sent but the receiver ignores.

**R7** – if the front panel rotary switch is set to “Remote,” this will change the range to ‘20mW auto.’ Byte 4 turns on Range Hold with a value of 1 and turns off range hold with a value of 0. Bytes 5-7 must be sent but the receiver ignores.

**R8** – if the front panel rotary switch is set to “Remote,” this will change the range to ‘200mW auto.’ Byte 4 turns on Range Hold with a value of 1 and turns off range hold with a value of 0. Bytes 5-7 must be sent but the receiver ignores.

**C0** – will set the calibration heater to “OFF” if the back panel Internal Calibration Switch is not set to “OFF.” Bytes 4-7 must be sent but the receiver ignores.

# Set, Query and Get Power Commands

## Set Commands: Continued

**C1** – will set the calibration heater to the preset value of 100  $\mu$ W if the back panel Internal Calibration Switch is not set to “OFF.” Bytes 4-7 must be sent but the receiver ignores.

**C2** – will set the calibration heater to the preset value of 1 mW if the back panel Internal Calibration Switch is not set to “OFF.” Bytes 4-7 must be sent but the receiver ignores.

**C3** – will set the calibration heater to the preset value of 10 mW if the back panel Internal Calibration Switch is not set to “OFF.” Bytes 4-7 must be sent but the receiver ignores.

**C4** – will set the calibration heater to the preset value of 100 mW if the back panel Internal Calibration Switch is not set to “OFF.” Bytes 4-7 must be sent but the receiver ignores.

## Query commands

**D1** – will request one power output sample. Bytes 4-7 must be sent but the receiver ignores. No response will be sent until new data is available, up to 1 sec on the 200  $\mu$ W range.

**DS** – will request streaming of power output samples, (data sent at the internal sample rate). Bytes 4 through 7 must be sent but the receiver ignores. Streaming will continue until the PM5B gets a ‘D1’ command or until the power is turned off. The internal sample rate is 1 Hz on 200  $\mu$ W range, 5 Hz on 2 mW range, 20 Hz on 20 mW range and 35 Hz on 200 mW range.

**VC** – will request the firmware code and secondary firmware code revision data. Bytes 4 through 7 must be sent but the receiver ignores.

## High Resolution Get Power Command

The PM4 command structure returns 16 bits representing measured power, which sometimes is not enough for the PM5B. An alternate command is available for the PM5B that has greater resolution.


Sending the following series of bytes will prompt the PM5B to return the measurement result over the USB with higher resolution:

[38, 1, 2, 37](#)

After receiving these bytes the PM5B will measure and return 14 bytes. The first returned byte is an error byte. If there was a communication error this byte will be 0xAB, otherwise it will be 0x55. The remaining 13 bytes will be an ASCII text string in exponential notation representing power in milliwatts.

The PM5B determines if there was a communication error by calculating the “Exclusive OR” result of the first three bytes in the command string and compares to the last byte sent. The last byte (37) in the command string is the “Exclusive OR” combination of the previous three bytes and must match the “Exclusive OR” result calculated by the PM5B.

To correct for the loss of the WR10 1-inch section and a waveguide taper, the WR10 1-inch section and various tapers were measured using calibrated VNA frequency extension modules for multiple frequency bands, from 90 GHz to 1.1 THz. Contact VDI for information on power measurements above 1.1 THz.



**Figure 7:**

Data for taper and PM5B sensor head loss for various frequency bands are shown. The loss through the PM5B Sensor Head includes loss through the 1" WR10SWG and internal waveguide losses. Internal waveguide loss is approximated to be the same as the loss through the 1" WR10SWG.

Based on the measurements, the scaling factor for a given waveguide taper can be approximated to a constant value. The dotted black lines indicate significant absorption regions through air (assuming 50% humidity).

Waveguide Band	Loss of PM5 Sensor Head including 1" WR10SWG (dB)	Loss of Waveguide Taper (dB)
WR10	0.17	N/A
WR8.0	0.17	0.13
WR6.5	0.18	0.16
WR5.1	0.19	0.18
WR4.3	0.19	0.28
WR3.4	0.19	0.32
WR2.8	0.20	0.35
WR2.2	0.20	0.40
WR1.9	0.25	0.50
WR1.5	0.30	0.65
WR1.2	0.35	0.85
WR1.0	0.40	1.05
WR0.65	0.60	1.50
WR0.51	0.70	N/A

**Figure 8:**

This table lists VDI correction factors for various waveguide bands.


## Current and Future Measurement Standards

There are no generally accepted standards for power measurements around 100 GHz and above. The purpose of "Appendix Two" is to describe the methods that VDI uses to measure power levels from VDI sources. In this way VDI hopes to keep its customers fully informed of its measurement techniques and foster a greater discussion of the best methods to perform such measurements. Possible methods to compare power measurements made by different research laboratories are also important topics, but they have not been considered here. VDI will update this document from time to time to reflect improved measurement techniques and equipment upgrades.

## Sensor Head



The PM5B's Sensor Head weighs approximately 8 ounces (about .22 kg). Despite its robust construction it should not be dropped or roughly handled since its internal components, connection points, and the Flange can be misaligned or damaged.







# PM5B Mechanical Drawing: WR10 1-Inch Taper

## WR10 1-Inch, Self-Symmetric Taper

THE INFORMATION CONTAINED IN THIS DOCUMENT IS THE PROPRIETARY PROPERTY OF VIRGINIA DIODES, INC.


WAVEGUIDE FLANGES:  
(2) WR-x.x/WM-xxx, UG-387/U-M



BASIC DIMENSIONS		
WAVEGUIDE	A1, A2	B1, B2
WR-15	3759 micron	1880 micron
WR-12	3099 micron	1549 micron
WR-10	2540 micron	1270 micron
WR-8.0	2032 micron	1016 micron
WR-6.5	1651 micron	825.5 micron
WR-5.1	1295 micron	647.5 micron
WR-4.3	1092 micron	546 micron
WR-3.4	864 micron	432 micron
WM-710 (WR-2.8)	710 micron	355 micron
WM-570 (WR-2.2)	570 micron	285 micron
WM-470 (WR1.9)	470 micron	235 micron
WM-380 (WR1.5)	380 micron	190 micron
WM-310 (WR-1.2)	310 micron	155 micron
WM-250 (WR-1.0)	250 micron	125 micron
WM-200 (WR-0.8)	200 micron	100 micron
WM-164 (WR-0.65)	164 micron	82 micron

WR-x.x/WM-xxx WAVEGUIDE:  
FLANGE UG-387/U-M  
(WR-10 SHOWN)

WR-x.x/WM-xxx WAVEGUIDE:  
FLANGE UG-387/U-M  
(WM-570 (WR-2.2) SHOWN)



NOTE: SPECIFICATIONS AND CHARACTERISTICS ARE TYPICAL AND SUBJECT TO CHANGE AT ANY TIME.

TITLE:  
**1" SELF-SYMMETRIC TAPER**

MODEL #:  
WRx.x-10TR3

MATERIAL:  
ALUMINUM ALLOY 6061-T6

REV. DATE:  
04/22/2014

REV.:  
R3V1

SHEET:  
1 OF 1

UNITS:  
INCH



ORIGINAL DRAWING BY: R. WENGER  
SEGARS ENGINEERING for:

VIRGINIA DIODES, INC.  
979 2nd ST. SE, SUITE 309  
CHARLOTTESVILLE, VA 22902  
PHONE: 434.297.3257  
FAX: 434.297.3258  
www.virginiadiodes.com

# Addendum — Product Updates and Company Contacts

Virginia Diodes' PM5B is an industry-leading solution for high frequency power measurement. Each generation of our Erickson calorimetric power meter incorporates advances in accuracy, speed, convenience and other benefits. Thanks to widespread industry acceptance, the PM5B has become a *de facto* standard for power measurement above 100 GHz.

The Virginia Diodes' staff of engineering and physical science professionals works to continually improve our products. We also depend upon feedback from colleagues and customers. Ideas to simplify the meter's operations, improve performance or add capabilities are always welcome. Be certain that Virginia Diodes has your latest contact details including a phone number and an email address to receive update advisories.



## Contact VDI:

### Virginia Diodes, Inc.

Web: <http://www.vadiodes.com>

Email: [Technical@vadiodes.com](mailto:Technical@vadiodes.com)

Telephone: 434.297.3257